Contact BlueAnt:

Nth America
customercare@myblueant.com
1 866 891-3032

Australia
customercare@blueant.com.au
1300 669 049

New Zealand
customercare@blueant.com.au
0800 443 122

LED Indicator Chart

Power ON	Solid Blue for 5 Seconds
Power OFF	Red flash 3 times
Pairing Mode	Blue flashing
Reset	Blue flashing
Charging	Solid Red
Charging with Power ON	Solid Red with a Purple Flash
Charging Complete	Red indicator OFF
Low Battery	All LED's change to Red
Idle	Blue flash every 8 seconds
Standby	2 Blue flashes every 5 seconds
Ongoing call	NO LED's

Z9i
BLUETOOTH HEADSET
Dual mic with Voice Isolation

BlueAnt®

Keep this in your wallet for quick reference

PAIRING

Before use, you must pair the headset with your cell phone. Pairing will create a stored connection in the Z9i and your Bluetooth cell phone. Pairing has to be done only once, when first connecting to a phone. The Z9i can store pairing information for five (5) different Bluetooth devices.

Pairing Procedure - This is an example procedure only.

These steps may differ from phone to phone, but the process will be the same.

1. First turn the phone OFF and then back ON again to refresh its memory.
2. Bring the mobile phone to about 30cm from the Z9i Dual Microphone.
3. Find the Bluetooth menu in your mobile phone. Turn Bluetooth ON. (Check your mobile phone user guide)
4. With the Z9i OFF, Press and Hold the MFB for about 6 seconds until the LED flashes Blue.
5. Your headset is now ready to be discovered by your Bluetooth mobile phone.
6. Perform a Bluetooth device discovery on your mobile phone to add a new device. It takes a few seconds to search for and find other Bluetooth devices around you.
7. When Bluetooth devices are found, the phone will display "BlueAnt Z9i". Scroll to it and press OK to confirm that you want to pair with it.
8. Enter the Passkey "0000" when your phone prompts you. The phone will now pair with the BlueAnt Z9i.
9. If your Bluetooth phone menu supports it "set as authorized" or "add to trusted devices"
10. Again select the BlueAnt Z9i to connect with it. OR, Press the MFB to connect with the phone.

Standby Mode means connected to a device but not on a call.

Idle Mode means the Z9i is ON but not connected to any device

Multiple button presses means click together

BUTTON FUNCTION MATRIX

MFB (Multi Function Button)

Volume Down

Volume Up

Z9i Function	Button	Time	Status
Power ON	MFB	3 Seconds	From OFF
Power OFF	MFB	3 Seconds	Idle/Standby
Enter Pairing Mode	MFB	6 Seconds	From OFF
Answer Call	MFB	Click	Ringing
End Call	MFB	Click	Active Call
Reject Call	MFB	1 Second	Ringing
Redial Last Number	MFB	3 Seconds	Standby
Voice Dial Activate	MFB	Click	Standby
Switch Voice Isolation between Standard and Max	MFB	1 Second	Active Call
Volume Up	Vol+	Click	Active Call
Volume Down	Vol-	Click	Active Call
Mute	Vol+	3 Seconds	Active Call

Advanced Z9i Functions			
Disconnect / Transfer	MFB & Vol+	Click	Connected
Multi-Point - Place phone 1 on hold and receive phone 2	Vol+	3 Seconds	Active
Multi-Point - End phone 2, return to phone 1	MFB	Click	Active
Multi-Point - End phone 1 receive phone 2	Vol-	3 Seconds	Active
Call Conference - receive simultaneously	MFB	3 Seconds	Active Call
Call Waiting - Active phone only	MFB & Vol-	3 Seconds	Active Call
Turn LED's OFF/ON	MFB & Vol+	3 Seconds	Idle/Standby
Reset Device	MFB & Vol-	Click	Idle