

## WHAT'S IN THE BOX

1. SW1 Switch
2. 18" Black Patch Cord
3. Blue and Burgundy Accents
4. User Guide

## COMPATIBILITY

**HEADSET COMPATIBILITY:** The following headset configurations are compatible with the SW1 Headset/Handset Switch.

- VXI Passport V-series headsets + QD1026V Cord
- VXI Passport G-series headsets + QD1026G Cord
- VXI Passport P-series headsets + QD1026P Cord
- Plantronics headsets + QD1026P Cord
- GN Netcom headsets + QD1026G Cord or GN MPA Amplifier Cord

**PHONE COMPATIBILITY:** Compatible with any corded phone as long as the number pad is on the base of the phone and not on the handset.


To attach a different colored accent, gently remove the accent on the switch by prying it up at either end (see photo right), and then replace it with the desired accent.




## SET UP

### 1 - CONNECT HEADSET



Plug your headset into the headset port. 


### 2 - CONNECT HANDSET



Plug your telephone handset into the handset port. 

### 3 - CONNECT PATCH CORD TO SWITCH



Plug black patch cord into the phone port. 

### 4 - CONNECT PATCH CORD TO PHONE



Plug the other end of the patch cord into the handset port on your phone.

## HOW TO USE THE SW1 HEADSET/HANDSET SWITCH

### USING A HEADSET

1. Press down the *headset* side of the switch.
2. To make or receive a call, remove the telephone handset from cradle. Dial as usual.
3. To end call, put handset back in the cradle.




### USING YOUR PHONE'S HANDSET

1. Press down the *handset* side of the switch.
2. To make or receive a call, use the telephone as usual.

### USING THE RECORDING PORT

The recording port will receive a standard audio cable with a 3.5mm plug for use with a recording device or a headset for monitoring both sides of the conversation.



## VXI LIMITED WARRANTY

1. If your SW1 Headset/Handset Switch fails to work for any reason during the first year from the date of purchase as shown by the purchaser's receipt of purchase, VXI will repair or replace the SW1 Headset/Handset Switch at its election, free of charge. To register your VXI product, you may do so online at [www.vxicorp.com](http://www.vxicorp.com) or by calling customer service at 800-742-8588. Without warranty registration, the warranty period begins on the date of manufacture. All products returned to VXI after the one-year warranty period will be repaired as "out of warranty" products, and purchaser will be billed for such repairs pursuant to the Out-of-Warranty Repair provisions set forth below.

2. The obligations of VXI under this warranty shall be limited to repair or replacement (at our option) of any part returned, freight pre-paid, to VXI. Returned products require a Return Authorization that may be requested from VXI at 800.742.8588 or [www.vxicorp.com](http://www.vxicorp.com).

3. THIS LIMITED WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, INCLUDING THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. Some jurisdictions do not permit the exclusion of implied warranties and the foregoing exclusions may not apply to you.

4. In no event shall VXI be responsible for any other damages whatsoever including direct, indirect, special, incidental, consequential or otherwise for breach of this or any other warranty, express or implied.

### OUT-OF-WARRANTY REPAIRS

VXI will repair out-of-warranty product for a charge that is applicable as of the date of receipt by VXI. Call 1-800-742-8588 for current repair charges and see return details above. Out-of-warranty repairs are warranted to be free from defects in material and workmanship for ninety (90) days.

## SW1 HEADSET/HANDSET SWITCH



One Front Street  
Rollinsford, NH 03869 USA  
[www.vxicorp.com](http://www.vxicorp.com)  
PN202310A

[www.vxicorp.com](http://www.vxicorp.com)

